

User manual for 4822 Door station Extender


(Version: V1.10)

1. Function

The door station extender is to extend the output port quantity for more extra door stations. In C-5 system, if a building has 3 or 4 or 5 entrances and needs door station each, the extender can be applied to connect with the output port for extra door station in a gate-way in order to have 4 extra output ports.

2. Parameters

- a) Working voltage: DC30 ~ 35V
- b) Static current: $\leq 15\text{mA}$
- c) Working current: $\leq 60\text{mA}$



3. System Diagram

